



DUETTA

Twin Filter Half Mask
P/N 102530000

DUETTA is an ideal facepiece for use in paint and pesticide spraying and in the handling of chemical products. Thanks to a soft sealing flap, it seats comfortably on the face, whilst the rigid shell firmly holds the cartridges and evenly distributes their weight.

DUETTA together with Spasciani snap-in cartridges series 2000 is the best value respirator.

Filtering cartridges can moreover hold special pre-filters that preserve the particle filter element from a too fast clogging up when used in particularly dusty environments.



TECHNICAL INFORMATION

Breathing Resistance

Test flow (l/min)	Inhalation (mbar)		Exhalation (mbar)	
	Standard max	Measured	Standard max	Measured
25 x 2	2,0	0,5	3,0	1,2
30	0,5	0,2	-	-
95	1,3	0,4	-	-

Inward Leakage (NaCl)

EN 140 standard requirement: < 2% Measured value: 0,07%.

Carbon dioxide content of the inhalation air

EN 140 standard requirement: < 1% Measured value: 0,3%.

LIMITATIONS FOR USE

Filter respirators cannot be used in environments where the oxygen content of the air is less than 17% in volume. **DUETTA** halfmask can only be used in conjunction with Spasciani filter cartridges series 2000. Please refer to the relevant notice for more information.



DUETTA

Twin Filter Half Mask

P/N 102530000

CLASSIFICATION

Half mask is III category PPE according to Regulation 2016/425/EU and is CE marked according to EN 140:1998 standard.

MARKING



MATERIALS

Half-face blank:	Composite plastic material (TPE + PP)
Head straps:	Elastic tape in polyester and rubber
Nape rest:	Nylon
Exhalation membrane:	Rubber
Snap-in connectors:	Shock & solvent resistant plastic material

STORAGE

Half masks can be stored in its original packaging until the expiration date (10 years). Store at temperatures between -20 and +50°C and with RH <80%, away from dust and corrosive vapours.

WEIGHT

80 g approx.

PACKAGING DIMENSIONS

The mask is packed in a polyethylene bag held in a box whose dimensions are 105x105x110 mm.
Masks are sold in 12 piece cartons whose dimensions are 460x140x350 mm.

For further information, refer to the instructions for use attached to the product and those published on the website www.spasciani.com

NOTE: SPASCIANI SpA does not take any responsibility for any possible and unintentional mistake and reserve the faculty of modify materials and technical characteristics of its products at any time and without any notice. The pictures are purely indicative and may not represent the actual product described in the text.